



Safety Precautions

Read the instruction manual thoroughly to operate the robot in a correct manner.

Robotics Operations FA Section

127 Toyooka, Kita-ku, Hamamatsu, Shizuoka 433-8103, Japan Tel. +81-53-525-8350 Fax. +81-53-525-8378

URL https://global.yamaha-motor.com/business/robot/ E-MAIL robotn@yamaha-motor.co.jp

RCXiVY2+SYSTEM

400,000 to

Parts registration

Search time reduced by

Maximum cable lengt

Monitoring Monitor output is provided

* Time depends on the workpiece.

Solutions RCXiVY2+ can provide:

Reducing teaching process time

Robot teaching work requires a lot of labor and time. The RCXiVY2+ system acts as "robot eye". The final fine positioning can be automated and greatly reduce the teaching time that was required for the conventional models.

Simplified positioning process

Reducing positioning process time in frequent lot change in small lot production.

Cost in preparation, control, and switching positioning jigs can be reduced.

Random workpieces need to be handled.

With position detection function of RCXiVY2+, pick & place operation of random shaped parts from parts feeder or pallet can be simplified.

RCXiVY2+ features:

- Adjusting parts orientation on the fly
- Conveyor follower
- Searching randomly placed parts
- **■** Top/bottom judgement
- OK/NG judgement

Conveyor tracking

With a feedback from encoder of a conveyor RCXiVY2+ can do pick & place following conveyor move.

Yamaha's comprehensive support of

Yamaha's integrated robot vision system. It means Yamaha supports both robot and vision system seamlessly.

Have any questions and don't know if it is robot



Robot and Vision

or vision related? Simply contact Yamaha representative. We have answers.

Simplicity

Setup is completed as little as eight minutes after power-on.

Auto-calibration makes setup easy.

Sophistication

With up to five million pixels,

a variety of workpieces can be supported. Improve throughput to 100 CPM with conveyor tracking.

Assurance

Comprehensive support covers everything from camera image acquisition to the operation of the gripper and robot.

With support that only the robot manufacturer can provide, you can relax.


Advanced RCX iVY2+ has been launched.

Increased application features

- Picking of irregular shape workpieces
- Presence inspection
- Multiple piece count

Enhanced performance

- CPU capability is increased to improve the search speed 8 to 45%.
- Number of pixels is increased.
- Frame rate is increased.



■ Supports template function of **RCX-Studio 2020**





High speed positioning of irregular shaped parts (foods or clothes)

Blob search function

Suitable for pick & place or detection of parts with wide tolerance in shape and size, or high speed counting.

Detection speed is 2 to 10 times faster that edge detection.







NEW

Detection time is shortened up to 45%. CMOS camera

By adopting a high-performance camera and improving the camera frame rate and CPU capability, detection time is reduced 8 to 45% while the resolution is improved.



Improved camera pixels

Improved camera frame rate

Improved CPU

Conventional iVY2 RCXiVY2+ [When one workpiece is detected.] [ms] 600 400 400 300 200 0.3M/0.4M 1.3M/1.6M 2M/3.2M 5M/5M

Easy operation

New features for easy operation



NEW

Suitable for parts detection and high volume parts count

Application examples

*Subject to application and condition

- Detection of electronics components Detection of screws and washers on PC board that secure parts
- Detection of accessories in package Checking drilled holes
- Counting of the number of bottles in pallet
 Counting of electronics components
- Detection of food labels

NEW

Overlap can be eliminated.

Overlapped workpieces are recognized and they can be excluded from the search target.

NEW

Detection with Speed


Comparing with edge search, blob search speed is 2 to 10 times faster.


Search speed


Up to 10 times faster



* Only doughnut shape workpieces are detected.









Suitable for traceability management

Code recognition function

Codes such as QR codes, data matrix codes, and barcodes can be recog-

This code recognition function is optimal for applications that change the operation corresponding to the code contents such as traceability management, workpiece sorting, and tracking change of sealing.

It is not necessary to separately purchase a handy terminal or code reader. Troublesome communication control is also not needed.



@YAMA!

- · QR code
- · Data matrix code
- Barcode (JAN/EAN-13 JAN/EAN-8 ITF NW7 CODE39 CODE128)
- * Up to 255 characters can be read.
- Only alphanumeric characters and symbols are supported.
 (2-byte characters such as HIRAGANA and KANJI characters cannot be read.)



Width of application is expanded.

Connection of multiple cameras

Up to eight cameras can be connected via HUB and support various applications such as addition of code recognition camera.



- 1 Workpiece supply position is corrected using the downward camera.
- ② Workpiece positioning or angle is corrected using the upward camera.
- 3 Place position is corrected using the downward camera.



Convenient for checking captured images

Images are saved automatically and can be checked easily on an external monitor.

These functions are very convenient when you want to check the captured images retrospectively during operation or debugging or save the images for traceability purposes.

Automatic image save function

Images can be saved to a USB memory automatically. An SSD or HDD that can be connected to a USB port can also be used.

Image save mode	All images / NG images / Disabled
Image size	Full size / Reduced size (320 x 240 pix.)
Overwrite save	Disabled/Enabled (The images are deleted from the oldest image when enabled.)

[Number of images that can be saved]

Number of images that can be saved when the memory size is 128 GB.

Number of camera pixels	Image size	Number of images that can be saved
0.4 million pixels	0.4MB	327680
1.6 million pixels	1.6MB	81920
3.2 million pixels	3.2MB	40960
5 million pixels	5.0MB	26214
Reduced.	0.08MB	1638400



Number of images that can be saved = Memory size / Image size 81920 images can be saved by 1.6 million pixels camera when 128 GB memory is used.

When the cycle time is 3 seconds, images for 68 hours can be saved.

History image function


Images can be displayed on an external monitor during searching.

The images and search results can be checked retrospectively with a USB mouse connected.

Past search images and results are checked.



Images in the memories (Nos. 0 to 15) are checked.



[Number of images that can be saved]


Number of camera pixels	Image size	Number of images that can be saved
0.4 million pixels	0.4MB	1250
1.6 million pixels	1.6MB	312
3.2 million pixels	3.2MB	156
5 million pixels	5.0MB	100

Area for history images 500 MB


Number of images that can be recorded to the history = 500 MB / Image size



[Robot controller integrated type]




Typical Robot Vision setup



- 1 Time consuming robot coordinates alignment.
- 2 Need to calculate compensation for moving
- 3 Operation deviation between the camera and robot due to communication time.
- 4 Adjustment of communication format is needed.

- Handling not easy
- Installation and setup costs
- Robot issue or vision issue? Who to call?


RCXiVY2+ system



- 1 Simple calibration function is incorporated.
- 2 Coordinates are corrected automatically even when the camera moves.
- 3 High-speed connections through dedicated bus line.
- 4 Controller is incorporated to provide the central operation.
- 5 Applicable to all models of YAMAHA robot lineup.

- Easy to use
- Various applications are supported using easy operation.
- Cost reduction by reducing work steps.
- Robot and vision supported by

Typical Robot Vision setup



Camera and robot have separate programs

RCXiVY2+ system

MOVE P. P9 VSEARCH 1,2,0 Searches for workpiece. P10=VGETPOS(0) Reads the point. MOVE P, P10 Moves to this point. No communication time lag Needs only few command lines. Simple and easy to understand

Centralized control using only the robot program

[Examples of program commands]

VSEARCH · · · Detect parts with designated camera


Camera and component type to be used for detection and the calibration data to be used can be switched with one command.

VSEARCH 1, 2, 1

- · Camera: 1
- · Component type number: 2

Component type number:


· Calibration data: 1



#01

VSEARCH 2, 3, 2

- · Camera: 2
- · Component type number: 3
- · Calibration data: 2



· · · Acquires the coordinates of the detected workpieces.

The search results can be substituted into the point coordinates directly.

VSEARCH 1, 2, 1


N = VGETCNT

· · · Detects the workpieces.

FOR J = 0 TO N-1

· · · Substitutes the number of detected workpieces.

P[J] = VGETPOS (J) · · · Acquires the workpiece coordinates.



#02

VGETPOS (0) \rightarrow Coordinates of 1

VGETPOS (1) → Coordinates of 2

VGETPOS (2) → Coordinates of 3

VGETPOS (3) → Coordinates of 4 VGETPOS (4) → Coordinates of 5 VGETPOS (5) → Coordinates of 6

* The order to substitute into VGETPOS can be selected from the following. 1) Score order, 2) X coordinate, and 3) Y coordinate

NEXT J

LVOLUME · · · · Intensity of light is adjustable from 0 to 100% range

In detection mode intensity of light can be adjusted with one command. Detection can be repeated with adjusted intensity.

> With a robot program of RCXiVY2+, retry detection with adjusted light intensity can be easily

· Light 1 is set to 10%. · Light 1 is set to 100%.




LVOLUME(1)=10



LVOLUME(1)=100

LVOLUME(1)=80 **VSEARCH** LVOLUME(1)=100 **VSEARCH** LVOLUME(1)=60 **VSEARCH ↓** NG Error process



[3 easy steps for parts registration]

From image acquisition, registration takes just three steps.



STEP. 2

Set the contour.

Contour is automatically extracted Paint the necessary contour with a




Search results

Register the detection position.

Specify the detection position with the mouse. Desired positions can be set.

STEP. 3





[Simple parts judgement process]



Contour setting pen

Paints the areas to be used from among the automatically detected edges.



Priority area pen

Paints the areas to be used as priority areas during search from among the edges.



Reduction area pen

Paints the areas where there should not be an edge during search.

[Usage example]





· Workpiece top or bottom judgement





Simple OK or NG judgement

Usage example of contour setting pen

When a workpiece with a partially different shape needs to be distinguished and recognized or when the top or bottom needs to be judged, the detection can be performed by painting the contours in different colors by combining the contour setting pen with the priority area pen and reduction area pen.



Blue: Normal contour setting

All contours are handled equivalently.




Green: Priority area setting

In addition to the blue area search, areas painted in green are used as priority areas to perform the judgement.



Yellow: Reduction area settin

When there is an edge in the unnecessary area painted in yellow, the score is reduced.



OK

The score may slightly vary depending on the presence status of the protrusion. However, both are detected.





When no edge is detected in the area set as priority area. this is judged as NG and the workpiece is not detected.






When an edge is detected in the area set as unnecessary area, the score is reduced and the workpiece is not detected.

[Simple calibration]

Conventional equipment combining "image processing unit + robot" requires many steps in "calibration" that aligns the camera coordinates with the robot coordinates. With the RCXiVY2+ system, following the wizard to perform the operation will complete the calibration easily within a short time. In addition, even when the setting position deviates, the calibration is executed and restored immediately.







[Calibration is automated with the dedicated jig.]

By automating the calibration using the advanced calibration function, highly accurate calibration can be achieved easily without depending on the operator's skill.

The hand data can also be created automatically and the time necessary for the calibration is reduced greatly.

Since the dedicated jig is the standard part (option part), the jig does not need to be designed and manufactured and can be used immediately.






[Setup time reduced greatly]

When using third-party vision, a coordinate conversion program needs to be created in the robot controller since the robot coordinate data differs from the vision format.

In RCXiVY2+, vision system is incorporated in robot controller the robot coordinate data can be stored into the robot point data using single process. This ensures very simple operation. Additionally, the unified control of the camera control and light control can be performed using the robot program. Start-up process will be greatly simplified.




[Easy link with peripheral equipment]

One controller provides unified control of robot, gripper, and lighting.



[System configuration illustration]



[Conveyor tracking]


Ideal for high-speed packaging arrangement high-speed transport of multiple types of items such as pharmaceuticals, cosmetics, and food products.

The vision camera detects the position and orientation of parts moving on the conveyor, and the robot picks them up.



Operating conditions: YK500XG / payload 1 kg (total of workpiece and tool) / horizontal movement 250 mm / vertical movement 1 mm / conveyor speed 100 mm/sec

[Improving productivity by controlling multiple robot systems]



Up to 254 types of parts registration


Setup changes require only that part numbers be changed. Setup changes are easy.




[High-precision search even under low light] [Monitor output]

Edge search engine is built-in

Supports a variety of applications while being minimally affected by the external environment.





Monitor the operating status

Monitor the search status while making calibration settings or during automatic operation.

- Selected type / Captured
- Search result
- (position score scale) Executed command
- Time required by

Output method

· DVI-I (supports digital monitor or analog monitor)




[Lens distortion and camera inclination correction function]

Mounting accuracy is improved. Camera is installed in the inclined status. *


The lens distortion and camera inclination when the angle of visibility is wide or when the camera is installed in the inclined status can be corrected.

When the distortion and inclination correction function is enabled during calibration, the calibration data for the distortion and inclination correction is created. When images are captured using this calibration data, captured images are corrected and output.




[Also supports moving camera]

Even if the camera is mounted on the robot, coordinates are











Even when the camera is moved, the coordinates are corrected automatically

[Easy-to-use programming software RCXiVY2+ Studio]

With programming software "RCXiVY2+ Studio", all vision related operations such as registration of fiducial marks and workpieces used for calibration (contour settings, various parameter settings, and read range settings), backup, restore operation, and operation monitor can be performed.

- Search trial-run, part type registration
- Reference mark registration (for calibration)
- Up to 254 workpiece types can be registered.
- Workpiece can also be added easily.
- Up to 100 workpieces can be detected at once.
- Data backup
- This software functions as a monitor during program operation.



[Easy programming]

Constructing the most suitable robot vision system for an application.

RCX-Studio 2020 program template function

Program is created automatically simply following step-by-step operating process

RCX3 series programming software RCX-Studio 2020 also has following five templates for vision system:




- Pallet picking using the vision
- Dispensing work using the vision
- Gripping deviation correction using the vision
- Gripping deviation and mounting position correction using the vision
- Gripping deviation and mounting position correction using the vision (without using any master)




Wide variety of robot system to choose from most suitable and economical solution for robot vision system











FLIP-X single-axis robots

^{*} The YA series is not supported

[Verifying application prior to purchase]

User's application is verified using actual sample parts before making a purchase decision.

Based on the evaluation result, recommendation will be made for most suitable and economical solution.



► For customers who consider to replace "iVY2" with "RCXiVY2+"

Workpieces that have been able to be recognized by the iVY2 system can also be detected by the RCXiVY2+ system under the same conditions without changing the installation position.

Therefore, it is not necessary to evaluate the workpieces again.


However, the exposure time and aperture may need to be adjusted.

In addition, since the installation hole positions of the camera are changed, the plate of the installation section

[Lot application examples]


Random flow of parts on conveyor

The workpiece positions are recognized by the camera and the labels are adhered to the determined positions on workpieces. The adhesion position can also be specified for each part type.




Automatically adjusting sealing points

Position of workpiece is correctly recognized by its shape. Changing setup or jig between production lot can be eliminated.



Adjusting screw fastening position


Vision camera recognizes actual hole position with wide tolerance and adjust fastening position.






"Pick-and-Assemble" in one motion

Pick up parts from a tray, adjust position on the fly and install directly.






Conveyor tracking

Pick-and-pace operation of randomly positioned parts on conveyor by SCARA robot. Position and orientation of parts are recognized by vision camera.




Irregular shape workpieces such as foods and clothes

Pick-and-place with conveyor tracking for parts with wide tolerance like foods and clothes.



Ordering method



Note1. Only one tracking board can be selected.

• Refer to the comprehensive catalog for details on the order format.

●Robot vision basic specifications

Item		RCXiVY2+ unit					
	Applicable controllers	RCX340/RCX320					
	Number of screen pixels	720(H) × 540(V) (400,000 pixels) 1440(H) × 1080(V) (1,600,000 pixels) 2048(H) × 1536(V) (3,200,000 pixels) 2592(H) × 1944(V) (5,000,000 pixels) Note1					
	Model setting capacity	254 models					
	Number of connectable cameras	2 cameras (8 units when the HUB is used.)					
	Connectable camera	GigE camera PoE: IEEE802.3af 1 ch up to 7W					
Basic specifications	External interface	Ethernet (1000BASE-T) Note2 USB 2.0 2Ch (Up to 5V 2.5W / ch)					
-	External monitor output	DVI-I Note3 Monitor resolution: 1024 × 768 Vertical periodic frequency: 60 Hz Horizontal periodic frequency: 48.4 kHz					
	Power supply	24 VDC +/-10%, Maximum 1.5 A					
	Dimensions	W45 × H195 × D130 (RCXiVY2+ unit only)					
	Weight	0.8kg (RCXiVY2+ unit only, when the lighting control board option is selected)					
	Operating environment	Compliant with the RCX340/RCX320 controller.					
	Storage environment	Compliant with the RCX340/RCX320 controller.					
Search meth	od	Edge search, Measuring search, Blob search, Code search					
Image	Trigger mode	S/W trigger, H/W trigger					
capturing	External trigger input	2 points					
Function		Position detection, coordinate conversion, automatic point data generation, distortion and inclination correction					
Camera insta	Illation position	Fixed to the fixed camera (up, down) or robot (Y-axis, Z-axis). Vertical direction to the image capturing target workpiece is recommended.					
Setting suppo	ort function	Calibration, image save function, model registration Note4, fiducial mark registration Note4, measuring registration Note4, blob registration Note4, code registration Note4, monitor function Note4					
	Number of connectable lighting units	Maximum 2					
Lighting cont options	rol Modulated light format	PWM modulated light control (0 to 100%), PWM frequency switchable 62.5 kHz/ 125 kHz Continuous light, strobe light (follows camera exposure)					
υμιιστιο	Lighting power input	12VDC or 24VDC (external supply shared by both channels)					
	Lighting output	For 12VDC supply: Total of less than 40W for both channels. For 24VDC supply: Total of less than 80W for both channels.					

Note1. Since the rolling shutter is used, the tracking is not supported.

Note2. For setting and monitor operations

Note3. Also usable with an analog monitor by using a conversion adaptor.

Note4. RCXiVY2+ Studio function (requires a Windows PC)


●Tracking board basic Specifications

Tracking bo	aru basic opecifications	
Item		Tracking board
	Applicable controllers	RCX340/RCX320
	Number of connected encoders	Up to 2 units.
	Encoder power supply	5VDC (2 counters total 500 mA or less) (Supplied from controller)
	Applicable encoder	26LS31/26C31 or equivalent line driver (RS-422 compliance).
Basic specifications	Input phase	$A, \overline{A}, B, \overline{B}, Z, \overline{Z}$
Specifications	Max. response frequency	2MHz or less
	Counter	0 to 65535
	Multiplier	4x
	Other	With disconnection detection function

■ RCXiVY2+ unit

The RCXiVY2+ unit adds robot vision to the RCX340/RCX320 robot controller





• RCXiVY2+ unit accessories Trigger input cable connector set

Model KX0-M657K-00

24V power supply connector Model KCF-M5382-00

● Support software for PC RCXiVY2+ Studio

RCXiVY2+ Studio is programming software for the RCXIVY2+ system that allows registering part types and reference marks as well as monitoring the work search status during automatic robot operation by connecting to the robot controller.



■ Environment

OS	Microsoft Windows XP / Vista (32 bit / 64 bit) / 7 (32 bit / 64 bit) / 8, 8.1 (32 bit / 64 bit) / 10 (32 bit / 64 bit)
CPU	Processor that meets or exceeds the suggested requirements for the OS being used.
Memory	Suggested amount of memory or more for the OS being used.
Hard disk	30MB of available space required on installation drive.
capacity	* Additional vacant space is required for saving images and data.
Display	800 x 600 dot, or higher, 32768 colors (16bit High Color) or higher (recommended)
Communication Port	Ethernet Port of TCP/IP

^{*} Microsoft, Windows XP, Windows Vista, Windows 7, Windows 8, 8.1, and Windows 10 are registered trademarks of the Microsoft Corporation, USA.

CMOS camera



Model	400,000 pixel	720(H) × 540(V)	KFR-M6541-00
	1,600,000 pixel	1440(H) × 1080(V)	KFR-M6541-10
	3,200,000 pixel	2048(H) × 1536(V)	KFR-M6541-20
	5,000,000 pixel	2592(H) × 1944(V)	KFR-M6541-30

Lens



	_	
	8mm	KCX-M7214-00
	12mm	KCX-M7214-10
	16mm	KCX-M7214-20
	25mm	KCX-M7214-30
odel	8mm (megapixel support)	KCX-M7214-40
	12mm (megapixel support)	KCX-M7214-50
	16mm (megapixel support)	KCX-M7214-60
	25mm (megapixel support)	KCX-M7214-70

^{*} Common to iVY2.

● Close-up ring




Model	0.5mm	KX0-M7215-00
	1.0mm	KX0-M7215-10
	2.0mm	KX0-M7215-20
	5.0mm	KX0-M7215-40

Camera cable

Cable for connecting the camera to the RCXiVY2+ unit.

Cable length (L)	Model
5m	KCX-M66F0-00
10m	KCX-M66F0-10
15m	KCX-M66F0-20



^{*} Common to iVY2.

Lighting control board

This board adds lighting control functionality to the RCXiVY2+ system. (Installed in the RCXiVY2+ unit when shipped)

Model KCX-M4403-L0

 Lighting control board accessories Lighting power cable connector

Model KX0-M657K-10

Tracking board

This board adds conveyor tracking functionality to the RCX340/RCX320 controller.

Model KCX-M4400-T0

 Tracking board accessories Tracking encoder connector

Model KX0-M657K-20

● LAN cable with shield cloth (5 m)

Model KX0-M55G0-00



Tracking encoder cable (10 m)

Model KX0-M66AF-00



Calibration jig (Large and small attachments are provided.)









^{*} Ethernet is a registered trademark of the XEROX Corporation, USA.


Dimensional outlines


RCX340+RCXiVY2+



Calibration iig










Camei


● CMOS camera (400,000 pixel / 1,600,000 pixel / 3,200,000 pixel / 5,000,000 pixel)


























Lens characteristics

			Aperture value [F No.]	Angle-of-view (degrees)								Closest
Lens		Focal length [mm]		KFR-M6541-00 (400,000 pixel camera)		KFR-M6541-10 (1,600,000 pixel camera)		KFR-M6541-20 (3,200,000 pixel camera)		KFR-M6541-30 (5,000,000 pixel camera)		approach distance
				Vertical	Horizontal	Vertical	Horizontal	Vertical	Horizontal	Vertical	Horizontal	[m]
8mm	KCX-M7214-00	8	F1.3-CLOSE	27.13	36.09	26.85	35.69	37.57	49.23	30.72	40.60	0.2
12mm	KCX-M7214-10	12	F1.4-CLOSE	17.23	23.01	17.05	22.74	24.11	31.95	19.57	26.03	0.3
16mm	KCX-M7214-20	16	F1.4-CLOSE	13.17	17.50	13.03	17.30	18.48	24.44	14.97	19.83	0.4
25mm	KCX-M7214-30	25	F1.4-CLOSE	8.57	11.42	8.47	11.29	12.05	16.01	9.74	12.95	0.5
8mm (megapixel support)	KCX-M7214-40	8	F1.4-F16	26.47	34.83	26.20	34.44	36.68	47.61	29.97	39.21	0.1
12mm (megapixel support)	KCX-M7214-50	12	F1.4-F16	17.49	23.19	17.31	22.92	24.47	32.19	19.86	26.23	0.1
16mm (megapixel support)	KCX-M7214-60	16	F1.4–F16	13.28	17.69	13.14	17.48	18.64	24.69	15.09	20.04	0.1
25mm (megapixel support)	KCX-M7214-70	25	F1.4-F16	8.62	11.48	8.52	11.34	12.12	16.09	9.80	13.02	0.15

Note. This table shows the angle-of-view for Yamaha's standard lenses. If the angle-of-view is greater, there might be more distortion at the edge of the image.

• Angle-of-view size, WD(Work distance), and magnification when close-up ring is used

Close-up			Lens							
ring [mm]				mm 7214-00		12mm KCX-M7214-10		imm 17214-20	25mm KCX-M7214-30	
	WD[mm]		200		3	00	400		500	
		KFR-M6541-00 (400,000 pixels)	97.8 ×	130.5	93 >	< 124	93 >	124	72.9 × 97.2	
None	Angle-of-view size	KFR-M6541-10 (1,600,000 pixels)	98.6 ×	130.5	93.7	× 124	93.7	× 124	73.5	× 97.2
None	X × Y [mm]	KFR-M6541-20 (3,200,000 pixels)	139.2	× 185.7	132.2	× 176.5	132.2	× 176.5	103.7	× 138.4
		KFR-M6541-30 (5,000,000 pixels)	112.3	× 150	106.7	× 142.5	106.7	× 142.5		k 111.7
	Opti	cal magnification	0.0	38	0.0	040	0.0	040	0.0	051
		WD[mm]	69.5	118.6	143	296.8	222	524.1	358.5	1269.4
	A	KFR-M6541-00 (400,000 pixels)	37.2 × 49.6	60 × 80	46.5×62	93 × 124	52.3×69.8	120 × 160	53.1 × 70.8	186 × 248
0.5	Angle-of-view size X × Y	KFR-M6541-10 (1,600,000 pixels)	37.5×49.6	60.4×80	46.8×62	93.7 × 124	52.8×69.8	120.9 × 160	53.5×70.8	187.5 × 248
0.5	X × Y [mm]	KFR-M6541-20 (3,200,000 pixels)	52.9 × 70.6	85.3 × 113.8	66.1 × 88.2	132.2 × 176.5	74.5×99.4	170.6 × 227.7	75.5×100.8	264.5 × 353
		KFR-M6541-30 (5,000,000 pixels)	42.7 × 57	68.8 × 91.9	53.3 × 71.2	106.7 × 142.5	60.1 × 80.2	137.7 × 183.8	61 × 81.4	213.5 × 285
	Opti	cal magnification	0.100	0.062	0.080	0.040	0.071	0.031	0.070	0.020
		WD[mm]	38.7	53.8	91.3	142.3	152	257.1	280.8	635.9
	Angle-of-view size X × Y [mm]	KFR-M6541-00 (400,000 pixels)	22.9 × 30.6	30 × 40	31 × 41.3	46.5×62	36.8 × 49.1	60.9 × 81.3	40.8×54.5	93 × 124
1.0		KFR-M6541-10 (1,600,000 pixels)	23.1 × 30.6	30.2×40	31.2×41.3	46.8×62	37.1×49.1	61.4 × 81.3	41.2×54.5	93.7 × 124
1.0		KFR-M6541-20 (3,200,000 pixels)	32.6×43.5	42.6×56.9	44×58.8	66.1 × 88.2	52.3×69.9	86.7 × 115.7	58.1 × 77.5	132.2 × 176.5
		KFR-M6541-30 (5,000,000 pixels)	26.3 × 35.1	34.4×45.9	35.5×47.5	53.3 × 71.2	42.2×56.4	70 × 93.4	46.9×62.6	106.7 × 142.5
	Optical magnification		0.162	0.124	0.120	0.080	0.101	0.061	0.091	0.040
		WD[mm]			65.4	90.8	114.5	168.1	230.9	424.7
	Angle-of-view size	KFR-M6541-00 (400,000 pixels)			23.1×30.8	30.7×40.9	28.1×37.5	40.4×53.9	33.5×44.6	62 × 82.6
1.5	X x Y	KFR-M6541-10 (1,600,000 pixels)			23.2×30.8	30.9×40.9	28.4×37.5	40.7×53.9	33.7×44.6	62.5×82.6
1.5	[mm]	KFR-M6541-20 (3,200,000 pixels)			32.8×43.8	43.7×58.3	40×53.4	57.5×76.7	47.6×63.6	88.1 × 117.6
		KFR-M6541-30 (5,000,000 pixels)			26.5×35.4	35.2×47.1	32.3×43.1	46.4 × 61.9	38.4×51.3	71.1 × 95
	Opti	cal magnification			0.161	0.121	0.132	0.092	0.111	0.060
		WD[mm]			50	65.1	91.2	123.6	196.3	319.1
	Angle-of-view size	KFR-M6541-00 (400,000 pixels)			18.5 × 24.6	23.1 × 30.8	22.9×30.6	30.4×40.6	28.6 × 38.1	47 × 62.7
2.0	X x Y	KFR-M6541-10 (1,600,000 pixels)			18.6 × 24.6	23.2 × 30.8	23.1 × 30.6	30.7×40.6	28.8 × 38.1	47.4 × 62.7
	[mm]	KFR-M6541-20 (3,200,000 pixels)			26.3 × 35.1	32.8×43.8	32.6×43.5	43.3 × 57.8	40.6×54.3	66.9×89.3
		KFR-M6541-30 (5,000,000 pixels)			21.2 × 28.3	26.5 × 35.4	26.3 × 35.1	35 × 46.7	32.8 × 43.8	54 × 72.1
	Opti	cal magnification			0.201	0.161	0.162	0.122	0.130	0.079
		WD[mm]							104.2	129
	Angle-of-view size	KFR-M6541-00 (400,000 pixels)							14.8 × 19.8	18.6 × 24.9
5.0	X x Y	KFR-M6541-10 (1,600,000 pixels)							15 × 19.8	18.8 × 24.9
0.0	[mm]	KFR-M6541-20 (3,200,000 pixels)							21.1 × 28.2	26.5×35.4
		KFR-M6541-30 (5,000,000 pixels)							17 × 22.8	21.4×28.6
	Opti	cal magnification							0.250	0.199

Note. WD is the lens tip reference.

Close-up			Lens							
ring [mm]			8 mm lens for megapixel KCX-M7214-40		12 mm lens for megapixel KCX-M7214-50		16 mm lens for megapixel KCX-M7214-60		25 mm lens for megapixel KCX-M7214-70	
None	WD[mm]		100		100		100		150	
	Angle-of-view size X × Y [mm]	KFR-M6541-00 (400,000 pixels)	53.1 × 70.8		37.2 × 49.6		27.3 × 36.4		24.9 × 33.2	
		KFR-M6541-10 (1,600,000 pixels)	53.5 × 70.8		37.5 × 49.6		27.5 × 36.4		25.1 × 33.2	
		KFR-M6541-20 (3,200,000 pixels)	75.5 × 100.8		52.9 × 70.6		38.8 × 51.9		35.5 × 47.3	
		KFR-M6541-30 (5,000,000 pixels)	61 × 81.4		42.7 × 57		31.3 × 41.9		28.6 × 38.2	
	Optical magnification		0.070		0.100		0.136		0.149	
0.5		WD[mm]	46	113.6	66.1	283.2	77.8	505.4	130.3	1232.2
	Angle-of-view size X × Y [mm]	KFR-M6541-00 (400,000 pixels)	28.1 × 37.5	59×78.7	25.8×34.4	90.7 × 120.9	22.4×29.8	120 × 160	22×29.3	186 × 248
		KFR-M6541-10 (1,600,000 pixels)	28.4×37.5	59.5×78.7	26×34.4	91.4 × 120.9	22.5×29.8	120.9 × 160	22.1 × 29.3	187.5 × 248
		KFR-M6541-20 (3,200,000 pixels)	40×53.4	83.9 × 112	36.7×49	129 x 172.1	31.8×42.5	170.6 × 227.7	31.3×41.7	264.5×353
		KFR-M6541-30 (5,000,000 pixels)	32.3×43.1	67.7×90.4	29.6 × 39.5	104.1 × 139	25.7×34.3	137.7 × 183.8	25.2×33.7	213.5 × 285
	Optical magnification		0.132	0.063	0.144	0.041	0.166	0.031	0.169	0.020
1.0	Angle-of-view size X × Y [mm]	WD[mm]			47.2	131.9	62.6	243	114.6	607.2
		KFR-M6541-00 (400,000 pixels)			20.1 × 26.8	45.9 × 61.2	18.8 × 25.1	60 × 80	19.6 × 26.2	93 × 124
		KFR-M6541-10 (1,600,000 pixels)			20.2 × 26.8	46.2 × 61.2	19 × 25.1	60.4 × 80	19.8 × 26.2	93.7 × 124
		KFR-M6541-20 (3,200,000 pixels)			28.5 × 38.1	65.3 × 87.1	26.8 × 35.8	85.3 × 113.8	27.9 × 37.3	132.2 × 176.5
		KFR-M6541-30 (5,000,000 pixels)			23 × 30.8	52.7 × 70.3	21.6 × 28.9	68.8 × 91.9	22.5 × 30.1	106.7 × 142.5
	Opti	ical magnification			0.185	0.081	0.197	0.062	0.189	0.040
1.5	Angle-of-view size X × Y [mm]	WD[mm] KFR-M6541-00 (400.000 pixels)			35.2 16.5 × 22	81.4 33.2 × 44.2	51.5 16.3 × 21.7	155.5 40 × 53.3	102 17.7 × 23.7	398.9 62 x 82.6
					16.5 x 22	33.4 x 44.2	16.3 x 21.7	40.3 × 53.3	17.7 × 23.7	62.5 x 82.6
		KFR-M6541-10 (1,600,000 pixels) KFR-M6541-20 (3,200,000 pixels)			23.5 × 31.3	33.4 × 44.2 47.2 × 63	23.2 × 30.9	40.3 × 53.3 56.8 × 75.9	25.3 × 33.7	88.1 x 117.6
		KFR-M6541-30 (5,200,000 pixels)			23.5 x 31.3 18.9 x 25.3	38.1 × 50.8	18.7 × 25	45.9 × 61.2	20.4 × 27.2	71.1 × 95
	Onti	ical magnification			0.225	0.112	0.228	0.093	0.209	0.060
	WD[mm]				0.223	0.112	43	111.7	91.5	294.7
2.0	Angle-of-view size X × Y [mm]	KFR-M6541-00 (400.000 pixels)					14.3 × 19.1	30.2 × 40.3	16.2 × 21.6	46.5 × 62
		KFR-M6541-10 (1,600,000 pixels)					14.4 × 19.1	30.4 × 40.3	16.3 × 21.6	46.8 × 62
		KFR-M6541-20 (3,200,000 pixels)					20.4 × 27.2	43 × 57.3	23.1 × 30.8	66.1 × 88.2
		KFR-M6541-30 (5,000,000 pixels)					16.4 × 22	34.7 × 46.3	18.6 × 24.8	53.3 × 71.2
	Optical magnification						0.259	0.123	0.229	0.080
	WD[mm]								53.9	107.2
5.0	Angle-of-view size X × Y [mm]	KFR-M6541-00 (400,000 pixels)							10.6 × 14.2	18.6 × 24.8
		KFR-M6541-10 (1,600,000 pixels)							10.7 × 14.2	18.7 × 24.8
		KFR-M6541-20 (3,200,000 pixels)							15.1 × 20.2	26.4 × 35.3
		KFR-M6541-30 (5,000,000 pixels)							12.2 × 16.3	21.3 × 28.5
	Optical magnification								0.349	0.200

Note. The above table shows the field of view when the standard lens and close-up ring are used. (Closest distance value is shown in No Close-up Ring column).

Note. If a close-up ring is not used, a WD less than the value shown in this table cannot be used.

Note. If a close-up ring is used, only WD in the region of this value can be used.

Note. Values in this table are for reference only; Actual values may vary.

MEMO